Types of Ethernet Cabling

Ethernet Cabling is used to hardware Components with Rj45 Jack. These cable are shielded and unshielded which is Connected with Server, Router, Switch, Hub, Repeater, Computer, Laptop, Modem.


Three Types of Ethernet Cabling

- Straight-Through Cable
- Crossover Cable
- Rollover Cable

Straight-Through Cable

- Router, Switch, Hub to PC
- Router to SWITCH

STRAIGHT THROUGH WIRING 568A




Crossover Cable

- PC TO PC
- SWITCH TO SWITCH
- HUB TO HUB

- ROUTER Direct TO PC
- HUB TO SWITCH

CROSSOVER WIRING 568B



Rollover Cable

Although rolled over cable isn't used to connect any Ethernet connections together, you can use a rolled over Ethernet cable to connect a host to a router console serial communication port.

ROLLOVER WIRING (CONSOLE CABLE)

